



! SAFETY PRECAUTIONS

All safety related codifications, symbols and instructions that appear in this operating manual or on the equipment must be strictly followed to ensure the safety of the operating personnel as well as the instrument.

If the equipment is not used in a manner specified by the manufacturer it might impair the protection provided by the equipment.

If there is physical damage to the unit then do not use it.

Read complete instructions prior to installation and operation of the unit.

⚠ WARNING

A. SETUP

- The hazard of electric shock, is present due to the presence of high voltages within the SVR.
- Do not install the SVR near heat source, water or in damp environments.
- Do not block off the ventilation openings of SVR.
- The unit should be opened, installed or serviced only by trained persons.
- Servicing of the unit should be carried out while ensuring compliance with all safe electrical work practices and use of protective equipment.


B. INSTALLATION

- Make sure that all cables used in the SVR system are properly insulated with no visible bare patches.
- For secure operation ensure the protective-earth connection to the system is proper.
- Make sure that no overload equipment is connected to the system.
- Ensure that the connections at input and output terminals of SVR are proper before switching ON the system.

C. OPERATION

- Do not disconnect any cable from the SVR during its operation.
- Before disconnecting the system ensure that the load is safely turned-off.
- Make sure that no fluids or any other foreign objects enter the SVR.

STARTUP, SHUTDOWN AND MANUAL BYPASS PROCEDURE



A. STARTUP

- Make sure that the Bypass-MCB located on the back-panel is in OFF position.
- Turn ON the Mains-MCB located on the front-panel.
- Wait 10s before turning ON the signal-switch.
- Turn ON the signal-switch located on the front-panel.

B. SHUTDOWN

- Turn OFF the signal-switch and then the Mains-MCB located on the front-panel.

C. MANUAL BYPASS

- Turn OFF the signal-switch and then the Mains-MCB located on the front-panel.
- Turn ON the Bypass-MCB located on the back-panel.

SPECIFICATIONS

Display Specifications

7 Segment LED Display	Regular input and output
Bar Graph LED	Load indication with resolution of 10%
LED Indication	Over-load, Over-voltage, Under-voltage, Over-current
Buzzer Indication	Power-on, Over-load, Over-voltage, Under-voltage, Over-current, Over-temperature

Technical Specifications

Eliminates voltage sags	Upto 50V (22% considering 230V nominal)
Swell compensation	Upto 50V (20% considering 230V nominal)
Compensation irrespective of phase	Yes
Compensation of depth & long disturbances	Continuous correction possible (24x7)


Input Specifications

Nominal Input Voltage	230V AC (L-N)
Input Voltage Range	180 - 280V AC (L-N)
Relaxed Input Voltage Range	160 - 300V AC (L-N)
Operating Frequency	47-65 Hz
Max. Rated Input Current	27A / 14A*
Input MCB Rating	40A X 1 Pole / 20A X 1 Pole
Input Connection	Barrier terminal [R, N & E]
Input Wire Size	4 sq.mm / 2.5 sq.mm*


Output Specifications

Output Voltage	220 - 230 - 240V L-N (Selectable)
Power Efficiency	Typically over 97% (with 20-100% load conditions)
Correction Initiation	Less than 20 msec
Voltage Compensation Technology	Upto 50V
Max. rated Output Current	PWM based IGBT switching 22A / 11A*
Voltage Regulation	±0.5%
Output Connection	Barrier terminal [L, N & E]
Load Bypass	Manual (Optional)


DIMENSIONS (All in mm)



TERMINAL CONNECTIONS



DISPLAY DESCRIPTION



No.	Description
1	Input Voltage
2	Output Voltage
3	Load (KVA)
4	Fault Over-Load, Over-Voltage, Under-Voltage, Over-Current

NOTE : *Marked values are only valid for SINE-1P-2.5-180/280V

CONFIGURATION MENU

Press **[+]** + **[T]** for 5sec. to enter configuration menu.

MAIN MENU

PSW **000**

Press **[S]** to edit the Password OR change the position of cursor while editing.
Press **[T]** to change / toggle the value.
Press **[C]** to confirm the edited value / move into new parameter
Default value : 100 [Fixed]

SUB MENU

Output Voltage **230**

Press **[S]** to edit the Output Voltage OR change the position of cursor while editing.
Press **[T]** to change / toggle the value.
Press **[C]** to confirm the edited value / move into new parameter
Default value : 230

Power Rating **5**

Press **[S]** to edit the Power Rating OR change the position of cursor while editing.
Press **[T]** to change / toggle the value.
Press **[C]** to confirm the edited value / move into new parameter
Default value : 5 / 2.5*

Over-Voltage Set **YES**

Press **[S]** to edit the choice for Over-Voltage Set OR change the position of cursor while editing.
Press **[T]** to change / toggle the value.
Press **[C]** to confirm the edited value / move into new parameter
Default value : YES

NOTE :
This parameter will only appear if YES is selected in Over-Voltage Set.

Over-Voltage **280**

Press **[S]** to edit the Over-Voltage OR change the position of cursor while editing.
Press **[T]** to change / toggle the value.
Press **[C]** to confirm the edited value / move into new parameter
Default value : 280

Under-Voltage **160**

Press **[S]** to edit the Under-Voltage OR change the position of cursor while editing.
Press **[T]** to change / toggle the value.
Press **[C]** to confirm the edited value / move into new parameter
Default value : 160

Slave ID **1**

Press **[S]** to edit the Slave ID OR change the position of cursor while editing.
Press **[T]** to change / toggle the value.
Press **[C]** to confirm the edited value / move into new parameter
Default value : 1

bdr **4**

Press **[S]** to edit the Baud Rate OR change the position of cursor while editing.
Press **[T]** to change / toggle the value.
Press **[C]** to confirm the edited value / move into new parameter
Default value : 4

df **1**

Press **[S]** to edit the Data Format OR change the position of cursor while editing.
Press **[T]** to change / toggle the value.
Press **[C]** to confirm the edited value / move into new parameter
Default value : 1

dfe **no**

Press **[S]** to edit the choice for Default OR change the position of cursor while editing.
Press **[T]** to change / toggle the value.
Press **[C]** to confirm the edited value / move into new parameter
Default value : NO

EHE **no**

Press **[S]** to edit the choice for Exit OR change the position of cursor while editing.
Press **[T]** to change / toggle the value.
Press **[C]** to confirm the edited value / move into new parameter
Default value : NO

NOTE : *Marked values are only valid for SINE-1P-2.5-180/280V

CONFIGURATION PAGE

PG.	DISPLAY	DESCRIPTION	RANGE		DEFAULT
			Min	Max	
A	PSW	Password	—	—	100
1	230	Output Voltage	220	240	230
2	5	Power Rating	1	5 / 2.5*	5
3	YES	Over- Voltage Set	Yes / No		YES
Press [T] and then [C] on page-3 to set over-voltage on page-3.1					
3.1	280	Over - Voltage	260	280	280
4	160	Under - Voltage	160	200	160
4	1	Slave ID	1	255	1
4	4	Baud Rate	1	5	4
4	1	Data Format	0	5	1
5	NO	Default	Yes / No		NO
6	NO	Exit	Yes / No		NO

MODUS REGISTER ADDRESS LIST

Readable parameters : [Length (Register) : 2 ; Data Structure : F32]

Address	Parameter
30000	Input voltage
30002	Output voltage
30004	Current
30006	Load percentage
30008	Fault Code

Readable / writable parameters for communication [Length (Register) : 1; Resolution : 1]

Address	Parameter	Range	Default	Data Structure
40000	Output voltage Set	220-240	230	u16
40001	KVA	1-5 / 2.5*	5 / 2.5*	u8
40002	Over-voltage selection	0-1	1	u8
40003	Over-voltage range	260-280	280	u16
40004	Under-voltage range	160-200	180	u16
40005	Slave ID	1-255	1	u16
40006	Baud rate	1-2400 2-4800 3-9600	4	u16
40007	Data format	0-8N1 1-8N2 2-8E1	0	u16

FAULT CODE DESCRIPTION

Fault Type	Decimal Value
Over-Current	2
Over-Load	4
Over-Voltage	8
Under-Voltage	16
Over-Temperature	32

ONLINE PAGE

Parameter	Default	Condition	Display position
Input Voltage	Vin	- - - -	Seven Segment Display: Left Hand Side
Output Voltage	Vout	- - - -	Seven Segment Display: Right Hand Side
KVA	ON	At step of 10%. Range - Min : 0% Max : 100%	LED Bar Graph
Over Load	- - -		LED : OL
Over Voltage	- - -	ON as per fault	LED : OV
Over Current	- - -		LED : OC
Under Voltage	- - -		LED : UV

“LEFT BLANK INTENTIONALLY”

ORDERING INFORMATION

Product Code	Supply Voltage	Certification
SINE-1P-2.5-180/280V	180 to 280V AC (L-N)	—
SINE-1P-5-180/280V	180 to 280V AC (L-N)	—

NOTE : *Marked values are only valid for
SINE-1P-2.5-180/280V

(Specifications are subject to change, since development is a continuous process.)

Selec Controls Pvt. Ltd., India

Factory Address :
EL-27/1, Electronic Zone, TTC Industrial Area, MIDC, Mahape,
Navi Mumbai - 400 710, INDIA.
Tel. No. : +91-22-41 418 419/430 | Fax No. : +91-22-28471733
Toll free : 1800 227 353 (BSNL/MTNL Subscribers only)
Website : www.selec.com | Email : sales@selec.com