




- 1) Turn power ON
- 2) The yellow “supply ON” LED will illuminate and all other LEDs flash for a while.



Key press	Display	Description
TST/RST Press 	P 25 50 75 T  %Δi	In test mode, all LEDs illuminate & trip relay energises, indicating proper operation of unit.

Key press	Display	Description
NONE	P 25 50 75 T  %Δi	For eg. If Δi (A) =10Amp & Leakage current=2.5Amp then LED '25' (green) glows

- A. For leakage current level < 25% - All bargraph LED's off
 - B. For leakage current level > = 25% - LED '25' glows
 - C. For leakage current level > = 50% - LED '25' & '50' both glows
 - D. For leakage current level > = 75% - LED '25', '50' & '75' glows
 - E. For leakage current level 95 to 105% - All LEDs glow after set trip time is over
- Protection relay is energised after set time delay is over.

NOTE : At CBCT error condition, red LED and other 3 green LED's are continuously blinking.

- NOTE :** 1. Applicable only when unit is in tripped condition and leakage current is less than 85% of tripped level.
2. The "TST/RST" button does not work in the absence of CBCT.

Key press	Display	Description
TST/RST Press 	P 25 50 75 T  %Δi	All LED's are switched off indicating output relay's "non tripped state"

Significance of the Test button :

Test button is used to check the proper functioning of the unit even in the absence of leakage current.

i.e To check the proper functioning of unit when there is no leakage current and CBCT connected to unit press the TST/RST button. On pressing TST/RST button, all LEDs glows and trip relay energises instantly showing that the unit is working properly.

NOTE : At CBCT error condition, red LED and other 3 green LED's are continuously blinking.

Significance of the Reset button :

When there is leakage current above the set value of current unit trips ie all LEDs illuminate. At that time to reset the unit to prior to the fault condition press reset button.

Reset enable level :

When leakage current increases above the set value of current unit trips & all LEDs glows indicating trip of the unit. At that time to reset the unit to previous condition (i.e prior to trip condition), leakage current should be minimize to less than 85% of set value. This value is known as reset enable value at which unit can reset.




Trip relay (Protection relay) :

When leakage current exceeds the set value, 1.Trip relay energises

Trip time delay :

The time taken by unit to trip when fault occurs is called trip time delay.

The time delay should be long enough to avoid nuisance tripping caused by harmless transients, yet fast enough to open the circuit when a hazard exists.

Product	Supply		
			
ELRA2M1-2-230V-CE-RoHS	230V AC (±15%)		—

Selec warrants the products to be free from defects in the materials and workmanship for a period of one year (or other period specified, if any) from the date of sale by Selec.

The warranty does not apply to defects resulting from any action of the buyer, including but not limited to improper handling, operating the product outside the specification limits or unauthorized disassembling / altering of the product. The warranty shall be VOID if the product shows evidence of having been tampered or being damaged due to usage in corrosive environment ; or current, heat, moisture or vibration ; improper specification ; wrong usage in an application ; misuse or other operating conditions outside of Selec's control.

Selec shall not be responsible for special, indirect or consequential damages, loss of profits or commercial loss in any way connected with the products, whether such claim is based on contract, warranty, negligence or strict liability.

In no event shall the responsibility of Selec for any act exceed the individual price of the product on which liability is asserted.

In no event shall Selec be responsible for warranty or other claims regarding the products unless Selec's analysis confirms that the products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification or repair.

(Specifications are subject to change, since development is a continuous process.)

Selec Controls Pvt. Ltd., India

Factory Address :
 EL-27/1, Electronic Zone, TTC Industrial Area, MIDC, Mahape,
 Navi Mumbai - 400 710, INDIA.
 Tel. No. : +91-22-41 418 419/430 | Fax No. : +91-22-28471733
 Toll free : 1800 227 353 (BSNL/MTNL Subscribers only)
 Website : www.selec.com | Email : sales@selec.com